



Objects: Motor holder (2 parts on top), 90deg connector (left), table clamp (next page) Material: Aluminium; Tolerances: \pm 0.1mm; Scale: 1:1

The motor holder is fitted for a ASTROSYN MY4001 motor ("Size 14 Mini Hybrid Stepper Motor").

. Motor Holder and 90deg connector are connected by a 10mm stainless steel rod that is clamped between part 1 and 2 (hatching) and inserted and fixed in the 10mm b

. The 90deg connector connects to a table clamp (part 5 and 6) by a 10x10mm stainless steel bar (grey hatching) and is used to adjust height.

The table clamp connects to the table using a M8 screw with a flattened tip or protective cap.

Licenced under the CERN OHL v1.1











